



# New Fox Part Number Codes - VCXOs

This is to decode the new part numbering scheme. All combinations are not available.

## Example FY7HCBM35.328

F	FY7	H	C	M	35	.	328
Company	Model	Voltage	Stability	Temp Code	Frequency before the decimal	Decimal or Custom Code	Frequency after the decimal
F=Fox	Y3H=FVM Series	H=2.5Volts+-5%	B=50ppm APR	F=-20 to +70C	000	A=TBD	000000
	Y5H=FVS Series	C=3.3Volts+-10%	C=75ppm APR	M=-40 to +85C		B=TBD	
	Y7H=VCS Series	B=3.3Volts+-5%	D=100ppm APR			C=TBD	
		A=5Volts+-10%	E=25ppm Stability/ 50ppm Pullability			D=TBD	
			F=50ppm Stability/ 50ppm Pullability				
			G=30ppm Stability/ 80ppm Pullability				
			H=25ppm Stability/ 100ppm Pullability				
			J=50ppm Stability/ 100ppm Pullability				
			K=100ppm Stability/ 100ppm Pullability				
			L=33ppm Stability/ 90ppm Pullability				
			M=95ppm APR				
			N=50ppm Stability/ Pullability 60ppm min, 150ppm max				